

RYO Optodist

- ① Manual gain control (sets either amplification/attenuation, vca initial level and/or overdrive gain).
- ② Gain LED (indicates gain or vca initial lvl).
- ③ Signal In Knob sets audio input level.
- ④ Gain CV Knob - attenuator for gain control cv input.
- ⑤ LED based limiter circuit (limits the signal thru a set of 4 LEDs).
- ⑥ CV Input (attenuator - gain cv) either opens VCA or increases distortion.
- ⑦ Limiter on/off switch - engaging the LED clipping will alter character of the distortion.
- ⑧ Audio Input.
- ⑨ Audio Output.

Width: 6hp

